



ASSEMBLY INSTRUCTION FOR DINNING CHAIR

MODEL NO. :Skiby Bench(1401001)



A



1

L



4

D



16

E



16

G



1